

1. set steel frame (a1.) in final location.
2. bolt baseplate assy. (b)(c) to center of frame (a) with a 3/4" wrench
3. install concrete tiles (d) on frame.
4. place frame cover (e) over frame/baseplate.
5. slide cover plate (f) on mast (g) before erecting umbrella.
6. secure umbrella in position with stark nob (h)
7. use a 1" wrench to adjust the leveling bolts on baseplate if needed.

